# Washing Machine V2

## Project 4, ESDM

# **Short description**

- 1. Create and test Simulink model with a state machine implementing the behavior of a washing machine.
- 2. Write a small report on the project:
  - a. briefly describe the overall design you chose (states, transitions etc).
  - b. put screenshots from the tests, to prove the tests work



Figure 1: Washing Machine

## Requirements

- 1. The washing machine has 3 programs
  - linen 90 degrees:
    - washing phase: rotate intermittently for 2.5 hours
    - heating phase: during washing, also heat water until 90 degrees is reached
    - rinse phase: pump water out, add new water, pump it out
    - add conditioner: adds the conditioner in the drum
    - spin phase: rotate fast for 2 minutes
  - · quick wash
    - washing phase: rotate intermittently for 30 minutes
    - heating phase: during washing, heat water until 40 degrees is reached
    - rinse phase: pump water out, add new water, pump it out
    - add conditioner: adds the conditioner in the drum
    - spin phase: rotate fast for 2 minutes
- 2. The Simulink model has the following inputs and outputs:

### Inputs:

- ProgramSelection (number, 0 to 3)
  - -0 = no program selected
  - -1/2/3 = the three programs above
- Cancel button
- WaterLevel (real number, 0 to 10 liters)
- WaterTemperature (number, 0 to 100 degrees)

#### Outputs:

- FillWater (boolean): when TRUE, water is allowed to enter the machine
- ActivatePump (boolean): when TRUE, water is pumped out of the machine
- HeatWater (boolean): when TRUE, the water heater is activated
- AddConditioner (boolean): when TRUE, pours the conditioner onto the laundry
- RotatingSpeed (number, 0 to 1000): specify the rotating speed of the drum
- Machine Status (integer):
  - -0 = IDLE
  - -1 = WORKING
  - -2 = NO WATER
  - -3 = HEATER FAULT
  - -4 = PUMP FAULT

- 3. The washing and heating phases are done as follows:
  - water is entered in the machine (FillWater = TRUE) until water level reaches 5 liters. Then the filling is stopped.
  - activate HeatWater until WaterTemperature reaches the desired temperature
  - then the drum is rotated with speed 20 for 5 seconds, then pause for 5 seconds, then keep repeating
- 4. The rinse phase is done as follows:
  - the pump is activated until water level drops to below 0.1
  - water is entered in the machine (FillWater = TRUE) until water level reaches 5 liters
  - the pump is activated again until water level drops to below 0.1
  - if the pump is activated for 1 minutes and the water level has not yet dropped below 0.1, the pump is broken. Stop the program and set the Status output to PUMP FAULT.

## 5. Adding the conditioner:

- when AddConditioner transitions from FALSE to TRUE, the conditioner lid is opened and the conditioner is applied on the laundry
- 6. The spinning phase is done as follows:
  - the drum is rotated with a fixed speed of 1000 rpm for 2 minutes
- 7. If the ProgramSelection input becomes 0 during an ongoing program, then stop the ongoing program, pump all water out, and stop
- 8. The ProgramSelection input is not allowed to change to a different program during an ongoing program (i.e. you don't need to consider the case when ProgramSelection changes from 1 directly to 2)
- 9. Use parameters from Matlab whenever for all values you consider necessary (e.g. duration of times etc.). Our customer may want to adjust the parameters at any time.
- 10. Test your state machine (use one/multiple separate test models if necessary)